						INSTALL ATION MOTES
	QTY	ITEM ADAPTER	PART NO.	DESCRIPTION RDANE ADAPTER	TORQUE	INSTALLATION NOTES
1	1	ADAPTER		BRAKE ADAPTER		
3	1	AXLE CHIP		AXLE FLIP CHIP, LEFT		
3		AXLE CHIP	3221002	AXLE FLIP CHIP, RIGHT		Apply groups to avia shaft and through the Stainless Staal
4	1	AXLE, REAR	2227000	REAR AXLE 12X 173MM, HARD BLACK ANO	10	Apply grease to axle shaft and threads. Use Stainless Steel Washer (3227006) on non-drive-side.
5	1	BB PORT COVER		SLAYER BB PLASTIC PORT COVER		waster (3227006) on non-unive-side.
6	6	BEARING				
7		BEARING		ENDURO 688 LLU MAX 16X8X5		
	6			ENDURO BEARING 6900 2RS MAX TYPE, 22X10X6 SIZE		
8	1	BEARING SLEEVE	1807028	BEARING EYELET CENTRE SLEEVE		A
9	1				8	Apply grease to pivot bolts, and Loctite 243 (blue) to screw
		BOLT	1800011	LINK BOLT, UPPER, M10X1.0, L:58.5, 6MM HEX		threads.
10	1				8	Apply grease to pivot bolts, and Loctite 243 (blue) to screw
		BOLT	1801004	LINK BOLT, LOWER, M10X1.0, L:70.5, 6MM HEX		threads.
11	1				15	Apply grease to inner bearing races and Loctite 243 to
		BOLT		MP BOLT, M10X1.25, L:75, 6MM HEX		female chain stay threads.
12	2	BOLT	1801007	DROPOUT BOLT, M8X1.0, L:30, 6MM HEX	8	Apply Loctite 243 to female seat stay threads.
						Torque only with correct shock and hardware installed.
13	1				8	Apply grease to shock bolts, and Loctite 243 (blue) to screw
		BOLT	1801018	SHOCK BOLT, M8X1.0, L:34.5, 5MMHEX		threads.
14	1	BOLT	1801019	SOCKET HEAD CAP SCREW; M5X8, BLUE LOCTITE	< 1	Apply Loctite 243 (blue) to male threads.
				·		Torque only with correct shock and hardware installed.
15	1				8	Apply grease to shock bolts, and Loctite 243 (blue) to screw
	_	BOLT	1807049	CSUNK BOLT, 8MM X 57MM X M6 INT.	_	threads.
16	2	BRG CUP		BEARING EYELET FOR 16X8X5 BRG		
17	2	BRG SPACER		EYELET BEARING SPACER, T:6.3, FOR 40 MM LINK WIDTH		
18	2	BUSHING, FOX	N/A	FOX IGUS BUSHING		
19						
	1	CANADIAN SHIELD 29		29" CHAINSTAY YOKE COVER		
20	1	CANADIAN SHIELD 275		27.5" CHAINSTAY YOKE COVER		
21	1	CHAINGUIDE		ONEUP CHAINGUIDE ASSEMBLY (1C0686)		
22	1	CHAINGUIDE BASE		BASE PART OF CHAINGUIDE		
23	1	CHAINGUIDE SLIDE		SLIDING PART OF CHAINGUIDE		
24	1	CHAINSTAY 27.5"/29"	1050120CBN/1050123	ALTITUDE/INSTINCT CHAINSTAY CARBON		
25	2	FLIP CHIP		FLIP CHIP, OUTSIDE, AL7075, BLACK ANODIZE.		
26	2	FLIP CHIP	1807004	FLIP CHIP, INSIDE, AL7075, BLACK ANODIZE.		
27	1	FRONT TRIANGLE	1060120CBN-1060126	ALTITUDE/INSTINCT FRONT TRIANGLE, CARBON		
28	1	FWD SHOCK YOKE	1091002	ALTITUDE FWD SHOCK YOKE		
29	1	FWD SHOCK YOKE	1091003	INSTINCT FWD SHOCK YOKE		
30	1	GROMMET	1800002	SLAYER BB PORT GROMMET, 85A		
31	1	HANGER	1091004	REAR DER. HANGER, EXT THREAD, STD MOUNT		
32	1	HT PORT COVER, LEFT		HT PLASTIC PORT COVER, M4, LEFT		
33	1	HT PORT COVER, RIGHT		HT PLASTIC PORT COVER, M4, RIGHT		
34	1	LINK		2021 INSTINCT LINK 27.5" (XS, S), 29" (S)		
35	1	LINK		2021 ALTITUDE LINK 27.5" M, S		
36	1	LINK		2021 ALTITUDE LINK 27.3 M, 3 2021 ALTITUDE/INSTINCT LINK 29" (M, L, XL)		
37	1	MP CHIP		MAIN PIVOTCHIP		
38	1	O-RING		O-RING, ID 24.5MM, W:1.50. NITRILE.		
39	1	PROTECTOR		DOWNTUBE PROTECTOR		
40	2	PROTECTOR		TAILGATE PROTECTOR		
41	1	PROTECTOR		CHAINSTAY PROTECTOR		
42	1	PROTECTOR		DOWNTUBE PROTECTOR XS, S, M (27.5")		
43	1	PRTOECTOR		SEATSTAY PROTECTOR		
44	2	SCREW	1801014	M6-1.0, 14MM LONG, SOCKET HEAD	12	Apply Loctite 243 to bolt threads.
45		SCREW		M6-1.0, 22MM LONG, SOCKET HEAD	8	Apply Loctite 243 (blue) to screw threads.
46	2	SCREW, M4X10	1800024-BK	C'SUNK SOCKET SCREW, M4x10mm, stainless black	< 1	Apply grease to bolt threads and tighten until snug.
47	2	SCREW, M4X10, Black	1801013	SOCKET HEAD CAP SCREW; M4X10	< 1	Apply Loctite 243 (blue) to male threads.
48	2	SCREW, M4X8	1807068-BK	C'SUNK SOCKET SCREW, M4x8mm, stainless black	< 1	Apply grease to bolt threads and tighten until snug.
49	1	SCREW, M5X10	18081520VT	C'SUNK SOCKET SCREW, M5-0.8x10MM. BLACK STAINLESS STEEL	2	Apply Loctite 243 (blue) to screw threads.
		· ·				Torque only with correct shock and hardware installed.
50	1		1		8	Apply grease to shock bolts, and Loctite 243 (blue) to screw
	-	SCREW, M6x12	180566-012-BK	FLAT HEAD C'SUNK SOCKET SCREW, M6-1.0 X 12mm, Stainless bla		threads.
51	1	SEATSTAY 27.5"/29"		ALTITUDE/INSTINCT SEATSTAY CARBON		
_		SHOCK	N/A	SHOCK 230X65mm		
52	1					
53	1	SHOCK BUSHING	N/A	SHOCK BUSHING, ID:12.7mm, OD:15mm, L:12.7mm, STEEL		
54	2	SHOCK REDUCER	N/A	FOX STD REDUCER FOR 25MM PIN		
55	2	SHOCK REDUCER	N/A	SRAM STD REDUCER FOR 25MM PIN		
56	1	SHOCK, PIN	N/A	SHOCK PIN: ID:8 x 25 mm LONG; ALUMINUM		
57	1	SLEEVE		TT BEARING SLEEVE, ID:10, OD:14, L:29		
58	1	SLEEVE	1800010	SS BEARING SLEEVE, ID:10, OD:14, L:41, NECKED		
59	2	SLEEVE	1800040	DROPOUT BEARING SLEEVE, OD:14, ID:8, T:1.8, 6061 ALU		
60	1	SLEEVE		MAIN PIVOT BEARING SLEEVE, OD:15, ID:10, T:39, 6061 ALU		
61	4	SPACER		LINK BEARING SPACER, OD:22, ID:10, T:2.5		
62	4	SPACER		DO BEARING SPACER, OD:16, ID:8, T:1.5, 6061 ALU		
63	2	SPACER		MP BEARING SPACER, OD:22, ID:10, T:2.65		
	1	HANGER NUT		HANGER/AXLE NUT FOR UDH COMPATIBLE HANGER	20	Apply Loctite 243 (blue) to threads.
_		1.03110EN NOT	1001008		20	
64		LIDH STOP	1001003	LIDH STODDER		
64 65	1	UDH STOP		UDH STOPPER		
64 65 66	1 3	WASHER	1800019	WASHER ID: 10.2, OD: 15.5, T: 1		
64 65	1		1800019 1801009			